Intercom external call station



To call an apartment please enter the apartment number followed by the bell symbol.

Once the call is answered please talk the the tenant.

Should it be required, the tenant will unlock the door from their handset to allow entry