












Operating Tilt and Turn Windows

The handles on tilt and turn windows have 3 positions – it may help to think of them as the hands of a clock. Trying to cause the window to open when the handle is positioned otherwise could risk damaging the hinges and misaligning the windows.

Position 1 – Handle vertical fully down – ‘Half past’ / 6 (o’clock) – Fully closed.

Position 2 – Handle horizontal – ‘Quarter past’ / 3 (o’clock) – To open window fully on side hinges.

Position 3 – Handle vertical fully up – ‘o’clock’ / (midday) – To tilt window open.

Handle position	Sash position	Symbol	Meaning
			Closed position of the sash
			Turn and fold position of the sash
			Opened tilt position of the sash
			Malpositioning of the sash

WHEN OPERATING WINDOWS BETWEEN TILT MODE AND TURN MODE, THE WINDOW MUST ALWAYS BE CLOSED FULLY BEFORE TRYING TO MOVE FROM ONE MODE TO THE OTHER.