

Operating Tilt and Turn Windows

The handles on tilt and turn windows have 3 positions. Trying to cause the window to open when the handle is positioned otherwise could risk damaging the hinges and misaligning the windows.

Position 1 - Handle vertical fully down - Fully closed.

Position 2 - Handle horizontal - To tilt window open

Position 3 - Handle vertical fully up - To open window fully on side hinges.



WHEN OPERATING WINDOWS BETWEEN TILT MODE AND TURN MODE, THE WINDOW MUST ALWAYS BE CLOSED FULLY BEFORE TRYING TO MOVE FROM ONE MODE TO THE OTHER.